What to verify before a commercial locksmith arrives

When a commercial property needs new locks or an upgrade to existing hardware, the visit from a locksmith can be far more productive if the building owner or manager prepares a few things in advance. A little forethought saves time on site and helps the technician fit the right components without return trips. The following points cover the main items to check before the appointment, whether the work involves a single storefront door or a multi-tenant office building.

Confirm the type of door and frame

Not all doors accept the same lock. A hollow metal door in a commercial corridor has different prep requirements than a wooden office door or an aluminium storefront. The locksmith needs to know the material, thickness, and whether the door has a standard 2 1/8 inch bore or a narrower cutout. If the door already has a lock, note whether it uses a cylindrical, mortise, or rim cylinder design. Taking a photo of the edge face and the front of the door can answer questions before any measuring begins.

The frame also matters. A steel frame with a reinforced strike plate behaves differently than a wooden frame. If the frame has a concealed closer or an integrated electric strike, mention that as well. Having this information ready means the technician can bring the correct backset, latch, and screws for the job.

Know the access control requirements

Many commercial properties use some form of electronic access control alongside mechanical locks. If the plan involves a keypad, card reader, or a networked system, the locksmith needs to understand how the existing wiring runs and where the control panel sits. Check whether the door has a power transfer hinge or a concealed wire path. If the system uses a separate electric strike, make sure the strike voltage matches the access control panel output.

For a master key system, decide in advance how many levels of access are needed. A simple two-level system with a grand master key and change keys is straightforward, but a multi-level hierarchy with sub-masters for different floors or departments requires a detailed chart. The locksmith can produce that chart, but the building manager should have a clear idea of which people or groups need which keys. This avoids confusion later and keeps the keying scheme organised from the start.



Check egress hardware and panic bars

Commercial doors that serve as exits must meet local fire and safety codes. Panic bars and egress hardware allow people to push open a door from the inside without turning a knob. If the door currently has a push bar that is sticky, noisy, or hard to engage, tell the locksmith about the symptoms. A bar that does not retract the latch fully can leave the door unsecured or cause a safety hazard during an evacuation.

Also think about the door closer. A closer that drags or slams shut puts extra wear on the lock and can make the door difficult to open. If the closer needs adjustment or replacement, the locksmith can handle that during the same visit. Keeping the door closer in good condition extends the life of the latch and the frame.

Inventory all existing keys and cylinders


Before the locksmith arrives, gather every key that currently works on the doors involved. If some keys are missing or have been copied without authorisation, note that as well. A restricted key system, where blanks are not available to the public, offers better security because it prevents unauthorised duplication. If upgrading to a restricted key system is part of the plan, the locksmith can re-pin the existing cylinders or install new ones that accept the restricted blank.

For a large property, a spreadsheet listing each door, its cylinder type, and the key that operates it is very helpful. It lets the technician see at a glance which cylinders need re-keying and which can stay as is. The same list can serve as the basis for the master keying schedule.

Understand the building usage patterns

Different businesses have different hours and traffic flows. A retail store that opens at 9 AM and closes at 9 PM needs a lock that can withstand frequent use and occasional abuse. A warehouse that sees shift workers coming and going at odd hours may benefit from a keypad that allows temporary codes for cleaning staff or delivery drivers.

Explain to the locksmith how the door is used every day. If employees prop the door open for deliveries, the lock might need an electric latch retraction feature or a delayed egress option. If the building has after-hours access for tenants only, a simple keyed lock might be fine, but a keypad or a fob system can offer more convenience and audit trails. The more the technician knows about the daily routine, the better the recommendation for reliable workplace lock solutions that match the actual operation.



Prepare the area around the door

Clear any furniture, boxes, or decorations that block access to the door and the frame. The locksmith needs room to work with drills, screwdrivers, and possibly a jig for boring new holes. If the door is in a tight corridor, move anything that could get in the way. A clean work area also reduces the chance of dust or debris falling into the lock mechanism during installation.

If the door has a drop ceiling or a suspended ceiling tile above it, check whether the tile lifts easily. The technician may need to run wires for an electric strike or a power transfer hinge. Having the tile clear saves time and avoids accidental damage.

Decide on the level of security needed

Not every commercial door needs a high-security cylinder. A storage room with little value inside can use a standard pin tumbler lock. A front door that contains expensive inventory or sensitive data deserves something stronger. High-security cylinders resist picking, drilling, and bumping. They also use restricted keyways that prevent a locksmith from cutting a duplicate without the original keyholder's permission.

Bump-resistant locks and smart locks with audit trails add another layer. If the property has multiple tenants, a master key system with a restricted keyway gives the landlord control while

giving each tenant a unique key that cannot be copied easily. The locksmith can explain the trade-offs between cost and security, but having a rough idea of what level of risk the building faces helps narrow the choices.

Verify the door alignment and condition

A door that sticks or rubs against the frame will cause any lock to wear prematurely. Before the locksmith works on the lock, check whether the door closes fully without forcing. If the door sags or the hinges are loose, that should be corrected first. The locksmith can often adjust hinges or replace worn hinge pins, but major alignment issues may require a carpenter or a door installer.

Look at the strike plate area. If the plate is cracked or the screws are stripped, the lock may not engage properly. A reinforced strike plate with longer screws adds strength against forced entry. Mention any visible damage so the technician can bring a replacement plate if needed.



Plan for future maintenance and expansion

Think ahead. If the business might add more doors later or switch to an integrated access control system, choose hardware that is compatible with that growth. A modular lock that accepts different cylinders or a keypad that can be added later without replacing the whole lock saves money down the road.

Ask the locksmith about warranty and service options. Some manufacturers offer lifetime warranties on mechanical parts, while electronic components have shorter coverage. Knowing the support terms helps decide between similar products. The goal is to install **reliable workplace lock solutions** that serve the property for years rather than months.

Taking a few minutes to run through these checks before the locksmith arrives leads to a smoother installation and a lock system that meets the building's actual needs. A prepared property owner gets a better result, fewer surprises, and a technician who can focus on the work rather than chasing missing information.